



Spline Diameter

The diameter of the housing spline that slides into the differential.

Seal Diameter

The diameter of the seal that goes into the differential.

Housing Diameter

The diameter of the housing that the boot seal is clamped against.

Number of CV Housing Splines

Total number of teeth that slide into the differential.

27 Teeth



1.165

1.380

2.665

20 Teeth Internal-B

Inner Race Spline Count

The number of teeth that are inside the inner race of the cv joint.

Stub Height

The overall length of the stub from the top of the housing.

2 5/8"

Mfg. Number

The number stamped onto the housing. This number is usually located at the top portion of the bell.